Mounting Instructions for Load Bearing Harness Systems:

The **H.U.M.P.** (Hydration Utility Multiple Platform) is an accessory pouch designed to encase and attach <u>complete</u> tube-delivery type hydration systems to load bearing equipment. It also doubles as an additional cargo storage pocket and attaches to buttpacks. Properly installed, the **H.U.M.P.** becomes a functional part of your load bearing equipment. Follow these simple instructions and you'll be good to go!

NOTE: <u>Do Not Use</u> bladders / reservoirs by themselves, as you will compromise the performance standards set by the manufacturer and possibly void your warranty.



Fig. 1 - Pass the upper webbing strap of the **H.U.M.P.** through the accessory gear loop on harness shoulder pad as shown.




Fig. 2 - Feed webbing back through both loops of slide. Pull excess webbing through slide and position the H.U.M.P. with its upper edge approximately 3 – 4 inches below the top of BDU collar.




Fig. 3 - To fix position and eliminate any possibility of slippage, back loop webbing through slide.




Fig. 4 - Pull tight, and she ain't going anywhere! The H.U.M.P. is properly positioned and backlooped in Fig. 4.




Fig. 5 - For the bottom side, wrap the lower straps around the belt and adjust for torso length (add about 1 - 2 inches of slack to compensate for fore and aft torso movements).

Again, back loop for a secure fit.

Mounting Instructions for A.L.I.C.E. Ruck Pack:

Strap




Fig. 1 - Position the H.U.M.P. between Ruck frame and pack as shown (make sure that the bottom of the H.U.M.P. is between the hip pad and frame).




Fig. 2 - Feed the upper straps of the H.U.M.P. behind the upper back pad, over the frame, and back through the double loop slide. Be sure to feed the H.U.M.P. straps *inside of the* Ruck shoulder straps to prevent the H.U.M.P. straps from slipping along the edges of the Ruck frame.




Fig. 3 - Take up the slack until the H.U.M.P. hangs approximately 1/2" to 1" from the lower edge of the upper back pad.





Fig. 4 - Feed the lower straps of the H.U.M.P. through the accessory slots in the ruck frame bottom and secure using the back loop method. NOTE: Make sure that the H.U.M.P. is allowed to hang below the frame bottom as in Fig. 1. Do not over tighten lower straps or your hydration system will not ride properly in the H.U.M.P.

Using the Shark-Bite Closure:



This fail-safe closure is unique in that it uses no Velcro, zippers, or buckles to secure it. Instead, the "Shark-Bite" uses a rigid "tooth and socket" approach, thus creating a fail-safe, durable and easy to use method for closing a pouch - only from Spec.-Ops.™ Brand.

- Lay the loose flap (# 1) over the slat flap (#2) on the pouch face.
- Fold flap #1 under flap #2, press flat, and that's it!

Reach up under the closure, grab the webbing loop and pull downwards. The "Shark-Bite" will open quickly and easily, but only by using this method!