

Sling-AK Combat Fighting Sling



Remove hardware (snap-hook & 5 tri-glides) from sling and pass end through sling loop on buttstock.




Add 2 tri-glides as shown, then slide these down sling approximately 38 inches, leaving about 1.5 inch gap between tri-glides.



Wrap sling around buttstock as shown.




Pass end through each tri-glide as shown to form a length of webbing long enough to stretch about 4 to 5 inches beyond front swivel loop on rifle.



4" to 5"

Front Swivel Loop



Add the remaining 3 tri-glides to sling in the sequence shown above. Note that step 2 above is feeding the sling through the quick-release buckle. Make sure that the quick-release buckle is facing in the direction shown to avoid having a twist in the shoulder strap portion once installation is completed.



Add snap-hook to end of strap, secure by passing webbing back through last tri-glide. Then snap to front sling loop on weapon.

NOTE: A key advantage of this sling system is its tensioned "Traverse" side strap. This step is where you adjust for optimal tension. Position the hook on the strap to ensure the highest tension possible when snapped to front sling loop on weapon.



Sling-AK properly installed and ready for action! Note buckle adjustment in foreground; use this to get the ideal fit for your body size. This feature also allows for quick size changes for fitting over body armor/heavy clothing. Reposition tri-glides on either side of quick-release buckle to change carry/balance position of weapon.

© 2003 Best Made Designs, LLC
1601 W. 15th Street
Monahans, TX 79756
(432) 943-4888
Fax (432) 943-5565
1-866-SPECOPS